

Свойство LastErrorMsg

BSTR LastErrorMsg;

Описание:

Только чтение. Содержит текст ошибки выполнения функции.

From: <https://wiki.ilexx.ru/> Штрих-М: Документация
Permanent link:
https://wiki.ilexx.ru/doku.php?id=%D0%BC%D0%B5%D0%BD%D0%B5%D0%B4%D0%B6%D0%B5%D1%80_%D0%BE%D0%BF%D0%BB%D0%9D%2-%D0%BF%D0%BE%D0%B4%D0%BA%D0%BB%D1%8E%D1%87%D0%85%D0%8D%D0%88%D0%85%D1%81%D0%B2%D0%BE%D0%B9%D1%81%D1%82%D0%B0%lasterrmsgrev-136552503
Last update: 2013/04/09 20:30

